

# FEEDING YOUR INNER 787B

## STEPS TO REFILL A ROTORBOTTLE™


### PRIME THE PUMP (SYRINGE) CLEAR TRAPPED AIR

Use a drop of oil to fully coat the rubber seal circumference (barrel plunger contact area) and fill the syringe with Idemitsu Pre-mix oil past the 20 ml/cc line and point the syringe up to allow trapped air to rise and oil to fall, purging most of the air out of the chamber. Keep slight pressure on plunger.



### FILL A ROTORBOTTLE™

Refill with Idemitsu Pre-mix oil approximately to the 76 ml/cc line, move over to the RotorBottle™ and fill it to the rim (2.5 oz).



### DRAIN BACK LEFTOVER OIL

After filling the last RotorBottle™, disassemble the pump (syringe), place the tube in the chamber and place the pump on the bottle's mouth to allow all the remaining oil to drain back.



### BRAP RESPONSIBLY

Participate and support your local Rotary club/scene AND regularly attend your local track.

